

**Door Harness Retrofit Camper Mirrors (S4Z)**

**ALL trucks require new door harnesses.**

RPO descriptions: DLF= Factory Mirror, DPO= Camper Mirror, BTM= PEPS (Keyless Start).

VEHICLE	CABIN STYLE	"AS BUILT" RPOs	Install new Door with:	Install Driver Door Harness	Install Passenger Door Harness	BCM need new Cals (for T/S, Clearance Lp, Cargo Lp)?
2020 LD (1500)	Dbl Cab (53) Crew Cab (43)	DLF-BTM (w/o PEPS)	DPO-BTM (w/o PEPS)	84622369	84622370	YES
	Regular Cab (03)			84622376	84622380	
	Dbl Cab (53) Crew Cab (43)	DLF & BTM (PEPS)	DPO & BTM (PEPS)	84622371	84622372	
2021 LD (1500)	Dbl Cab (53) Crew Cab (43)	DLF-BTM (w/o PEPS)	DPO-BTM (w/o PEPS)	84622369	84622370	
	Regular Cab (03)			84622376	84622380	
	Dbl Cab (53) Crew Cab (43)	DLF & BTM (PEPS)	DPO & BTM (PEPS)	84622371	84622372	