

Door Harness Retrofit Camper Mirrors (\$4Z)

ALL trucks require new door harnesses.

Note: The Camper mirrors can only be placed on vehicles that have DLF factory mirrors without Task Lamps (U12) and without Lane Change Alert (UKC). The camper mirrors will NOT function on a vehicle originally built with factory built DEN or DEZ mirrors.

VEHICLE	CABIN STYLE	"AS BUILT" RPOs	Install Driver Door Harness	Install Passenger Door Harness	BCM need new Cals (for T/S, Clearance Lp, Cargo Lp)?
2020 LD (1500)	Dbl Cab (53) Crew Cab (43)	DLF-BTM (w/o PEPS)	84622369	84622370	YES
	Regular Cab (03)		84622376	84622380	
	Dbl Cab (53) Crew Cab (43)	DLF & BTM (PEPS)	84622371	84622372	
2021 LD (1500)	Dbl Cab (53) Crew Cab (43)	DLF-BTM (w/o PEPS)	84622369	84622370	
	Regular Cab (03)		84622376	84622380	
	Dbl Cab (53) Crew Cab (43)	DLF & BTM (PEPS)	84622371	84622372	

RPO descriptions: DLF = Factory Mirror, BTM = PEPS (Keyless Start, aka "Push to Start")